

# intelligent | kit

## INSTALLATION MANUAL

The installation of INTELLIGENT KIT is a plugin work, expansive collage with foam and adjustment without screws or cutting. This is achieved through the prior study of Installation location and technical inspections. To ensure the quality of the placement, the installer should follow the following steps:

1. Check the door sticker to confirm that matches their specific place.
2. Check if the size of the vain (height, width and thickness) are in agreement with the corresponding door, and check for any imperfection in the plumb.
3. Remove the packaging.
4. Check direction of opening the door before placing it in vain.
5. Place the door in vain, dividing the space between the door-post and the wall, with the same line inside of the room, set the wedges with the assistance of a hammer, and check the plumb and alignment gaps, ensuring that the door is in the square.
6. Place the door handle to make viable the passage though the vain for the settings of the plumb and door alignment.
7. Check operation of the door, which should be opened and closed freely.
8. Wet the area where the foam will be applied.
9. Apply the foam (shake the tube before use) where the spacers are grouped, and the height of each hinge should be adjusted 3 of them in a way that occupy a maximum of 30 cm.
10. The curing of the foam takes 12 to 24 hours, only after that can be removed the latches, spacers, and cutting the excess foam with a stylus.
11. To install the trims, first of all, it is necessary to check the label to make sure it matches the door in question, open the packaging, check the specific pieces of regulation and counterbore to use them in the correct locations, and then just fit them in the corresponding channels on the door-stops.
12. Fit the lower finish of the doortrims (canoplas).
13. Finally, install the door lock finishes.



**3P KIT INTELIGENTE DO NORDESTE LTDA:** CNPJ 13.121.537/0001-51 - INSC. EST. 27.130.370-0 – INSC. MUN. 14-000087  
Highway BR 101, KM 118, Lot 3, Industrial District, S/N - Itaporanga D’Ajuda - Sergipe ZIP Code: 49.120-000  
Tel.: +55 79 3264-3600

**GHIFER EMPREENDIMENTOS IMOBILIÁRIOS LTDA:** CNPJ 05.415.640/0001-86 - INSC. MUN.134.298-9  
Street Fernandes Couto, 45 - São Francisco - Niterói - Rio de Janeiro ZIP Code: 24.365-150  
Tel.: +55 21 2720-2562/ 2611-5033

# intelligent | kit

## Remarks:

1. For installation of the doors, the floor, doorstep, lining and ceiling should be completed and the walls should be with the first coat of paint and / or final coat;
2. During the process of curing of the foam the door cannot be moved;
3. Damages caused in the paint during installation should be retouched.

**3P KIT INTELIGENTE DO NORDESTE LTDA:** CNPJ 13.121.537/0001-51 - INSC. EST. 27.130.370-0 – INSC. MUN. 14-000087  
Highway BR 101, KM 118, Lot 3, Industrial District, S/N - Itaporanga D'Ajuda - Sergipe ZIP Code: 49.120-000  
Tel.: +55 79 3264-3600

**GHIFER EMPREENDIMENTOS IMOBILIÁRIOS LTDA:** CNPJ 05.415.640/0001-86 - INSC. MUN.134.298-9  
Street Fernandes Couto, 45 - São Francisco - Niterói - Rio de Janeiro ZIP Code: 24.365-150  
Tel.: +55 21 2720-2562/ 2611-5033